


SEIKO PICK UP MICROPHONE STM30

INSTRUCTIONS









FOR SAFE OPERATION



Do not disassemble, attempt to repair or tamper with the microphone. A malfunction may result.

Do not drop or hit the microphone against hard surfaces. A malfunction or injuries may result.

Do not use the microphone for any other purposes than tuning. A malfunction or injuries may result.

HOW TO USE

- 1. Put the plug 2 of STM30 into the input jack of the tuner.
 - Clip STM30 microphone onto the instrument.
 For stringed instruments: Clip STM30 onto the center of the bridge.
 For brass and wood wind instruments: Clip STM30 onto the bell of the instrument.
 For acoustic guitars: Clip STM30 onto the head of the guitar.
- 3. Tune the instrument.
 - STM30 directly picks up the vibration of the instrument without being affected by the sound of other instruments or the noise around you.
- 4. After the tuning is completed, be sure to detach STM30 from the instrument.